




Track, Analyze & Improve Fleet Operations

Seamlessly integrate your Motive devices with Fleetio

Admin Users can log in to their Fleetio account and select Vehicles > GPS Integrations from the menu on the left to add their Motive credentials.

All Motive devices are then listed and can be mapped to the appropriate asset in Fleetio.



Benefits

